

Registration
Flight Number
Date

dd/mm/yy						
----------	--	--	--	--	--	--

DOW - Dry Operating Weight
Corrections (+ ou -)

35400
85
0

DOW - Corrected Dry Operating Weight
TOF - Take Off Fuel
OW - Operating Weight

= 35485
+ 11790
= 47275

PASSENGERS

Local Passengers

Adult Weight Regular
Adult Weight Charter

Nbre Pax	90
Forfait Pax	84

7560

Transit Passengers

Adult Weight Regular
Adult Weight Charter

Pax Transits	0
Forfait Pax	84

0

TOTAL PAX WEIGHT

A 7560

BAGS

Estimated local Bags

Tare - Local ULD Weight

Estimated Transit Bags (Gross Weight)

Nbre ULD	0
Poids ULD	90
Forfait bag	0

990
0
0

TOTAL BAGS WEIGHT

B 990

CARGO

Estimated Local Cargo

Estimated Transit Cargo

75
0

TOTAL CARGO WEIGHT

C 75

MAILS

Estimated Local Mail

Estimated Transit Mail

45
0

TOTAL MAIL WEIGHT

D 45

TOTAL DEADLOAD

B+C+D 1110

TOTAL PAYLOAD

PRE-CALC

8670

DOW - Corrected Dry Operating Weight

+ 35485

EZFW - Estimated Zero Fuel Weight MZFW

= 44155

49713

TOF - Take off Fuel

+ 11790

TOW - Take Off Weight

= 55945

MTOW or OTOW

62822

TIF - Trip Fuel

- 9900

LDW - Landing Weight

= 46045

MLDW

52770

LIMITATIONS

MZFW		MLDW
49713	↓ ↓ ↓ ↓ ↓ ↓	52770
Take Off Fuel	↓ ↓ ↓ ↓ ↓ ↓	Trip Fuel
+ 11790	↓ ↓ ↓ ↓ ↓ ↓	+ 9900
Limitation ZFW	MTOW	Limitation LAW
= 61503	62822	= 62670
OW - Operating Weigh	OW - Operating Weigh	OW - Operating Weight
- 47275	- 47275	- 47275
Allowed Traffic Load	Allowed Traffic Load	Allowed Traffic Load
= 14228	= 15547	= 15395
Payload/Total Traffic L	Payload/Total Traffic L	Payload/Total Traffic Load
- 8670	- 8670	- 8670
Underload Before LMC	Underload Before LMC	Underload Before LMC
= 5558	= 6877	= 6725

DOI - Dry Operating In 21,63
Passengers Distribu OA 30
OB 30
OC 30

OA	90	X	48	29,39	30
147					
OB	90	X	48	29,39	30
147					
OC	90	-	30	- 30	30
OA OB					

Cross Check

Weight	+	Underload Before L	=	Maxi Limitation
44155		5558		49713

B737-300

LOAD INSTRUCTION REPORT

PREVISION						
SOUTE 1			Ailes	SOUTE 4		
Compartment 11	Compartment 12	Compartment 13		Compartment 41	Compartment 42	Compartment 43
Max 763	Max 388	Max 1118		Max 2337	Max 414	Max 718
				BES/BY/990/R	BES/M/45	BES/C/40.RFG BES/C/25.RXS BES/C/10.RFS
Porte Soute				Porte Soute		

FINAL						
SOUTE 1			Ailes	SOUTE 4		
Compartment 11	Compartment 12	Compartment 13		Compartment 41	Compartment 42	Compartment 43
Max 763	Max 388	Max 1118		Max 2337	Max 414	Max 718
Porte Soute				Porte Soute		

LOADING INSTRUCTIONS

Bonjour, Chargez tous les bagages dans le compartiment 41, chargez ensuite les 3 colis de cargo en compartiment 43. Pour finir mettre les sacs de poste en compartiment 42. Merci

Commodity

BY	Bagage Economique
BC	Bagage Business
BF	Bagage First
C	Cargo
M	Mail
E	EIC